



## Parts List: 1239

Part Number	Description
12391X	Main Chassis Assembly
12392X	Inner Chassis Assembly
12393X	Lamp Assembly Module
12394X	Front Lens Assembly w/ Lens
12395X	Rear Lens Trolley w/ Lens
12396X	Color Boomerang
12397X	Front Cowling
12399X	Shutter Assembly
39121	Front Guide Rods
1239109	Front End Plate
39112	Front Top
39112R	Rear Top
39113	Lamp Baffle
39127	Aperture Cover
39129	Front Lens Locking Bar
120629	Housing Knob
S10-32X8P	Screw (#10-32 x 8" Phillips Pan Head)
S8-32X3/8PP	Screw (#8-32 x 3/8" Long Phillips)
S8-32X3/8F	Screw (#8-32 x 3/8" Slotted Hex)
S1/4-20X5/8PT	Screw (1/4-20 x 5/8" Long Phillips)
W8SL	Washer (#8, Split Lock)
S10-32X3/4P	Screw (#10-32 x 3/4" Long Phillips)
12338X	Fader Assembly

Call for current pricing. All prices subject to change without notice.

**Looking for a part? Our team is ready to help—call 845.469.2285 for fast, friendly assistance!**